

BLANC - WHITE - BLANCO



234342  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
22 CM - 8 IN<sup>11/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



235064  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
18 CM - 7 IN<sup>7/16</sup>  
70 CL - 23 OZ<sup>5/16</sup>



234341  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE/BOL  
17,5 CM - 6 IN<sup>7/8</sup>  
140 CL - 47 OZ<sup>5/16</sup>



209384  
**ASSIETTE/COUVERCLE  
DE COCOTTE ROND**  
ROUND PLATE/CASSEROLE LID  
BOL/PLATO PAN RONDO  
12,5 CM - 4 IN<sup>15/16</sup>



234340  
**BOL**  
BOWL  
BOL  
16 CM - 6 IN<sup>5/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



186849  
**BOL**  
BOWL  
BOL  
12 CM - 4 IN<sup>3/4</sup>  
30 CL - 10 OZ<sup>1/8</sup>

209383  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE BOL  
14 CM - 5 IN<sup>1/2</sup>  
50 CL - 16 OZ<sup>5/16</sup>

BLANC SABLÉ - SANDY WHITE - ACABADO COLOR ARENA



234345  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
22 CM - 8 IN<sup>11/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



235065  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
18 CM - 7 IN<sup>7/16</sup>  
70 CL - 23 OZ<sup>5/16</sup>



234344  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE/BOL  
17,5 CM - 6 IN<sup>7/8</sup>  
140 CL - 47 OZ<sup>5/16</sup>



209384  
**ASSIETTE/COUVERCLE  
DE COCOTTE ROND**  
ROUND PLATE/CASSEROLE LID  
BOL/PLATO PAN RONDO  
12,5 CM - 4 IN<sup>15/16</sup>



234343  
**BOL**  
BOWL  
BOL  
16 CM - 6 IN<sup>5/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



211893  
**BOL**  
BOWL  
BOL  
12 CM - 4 IN<sup>3/4</sup>  
30 CL - 10 OZ<sup>1/8</sup>

209720  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE BOL  
14 CM - 5 IN<sup>1/2</sup>  
50 CL - 16 OZ<sup>5/16</sup>

CARBONE - CARBONE/BLACK - NEGRO



234336  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
22 CM - 8 IN<sup>11/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



235066  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
18 CM - 7 IN<sup>7/16</sup>  
70 CL - 23 OZ<sup>5/16</sup>



234335  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE/BOL  
17,5 CM - 6 IN<sup>7/8</sup>  
140 CL - 47 OZ<sup>5/16</sup>



204042  
**ASSIETTE/COUVERCLE  
DE COCOTTE ROND**  
ROUND PLATE/CASSEROLE LID  
BOL/PLATO PAN RONDO  
12,5 CM - 4 IN<sup>15/16</sup>



234334  
**BOL**  
BOWL  
BOL  
16 CM - 6 IN<sup>5/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



234209  
**BOL**  
BOWL  
BOL  
12 CM - 4 IN<sup>3/4</sup>  
30 CL - 10 OZ<sup>1/8</sup>

204041  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE BOL  
14 CM - 5 IN<sup>1/2</sup>  
50 CL - 16 OZ<sup>5/16</sup>

BLEU - BLUE - AZUL



234339  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
22 CM - 8 IN<sup>11/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



235063  
**GRANDE ASSIETTE COCOTTE**  
LARGE CASSEROLE PLATE  
GRANDE COCOTTE/PLATO  
18 CM - 7 IN<sup>7/16</sup>  
70 CL - 23 OZ<sup>5/16</sup>



234338  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE/BOL  
17,5 CM - 6 IN<sup>7/8</sup>  
140 CL - 47 OZ<sup>5/16</sup>



230820  
**ASSIETTE/COUVERCLE  
DE COCOTTE ROND**  
ROUND PLATE/CASSEROLE LID  
BOL/PLATO PAN RONDO  
12,5 CM - 4 IN<sup>15/16</sup>



234337  
**BOL**  
BOWL  
BOL  
16 CM - 6 IN<sup>5/16</sup>  
100 CL - 33 OZ<sup>13/16</sup>



230822  
**BOL**  
BOWL  
BOL  
12 CM - 4 IN<sup>3/4</sup>  
30 CL - 10 OZ<sup>1/8</sup>

230821  
**COCOTTE**  
ROUND CASSEROLE  
COCOTTE BOL  
14 CM - 5 IN<sup>1/2</sup>  
50 CL - 16 OZ<sup>5/16</sup>





211891  
**MINI BOL**  
MINI BOWL  
MINI BOL  
7,3 CM - 2 IN<sup>7/8</sup>  
7 CL - 2 OZ<sup>3/8</sup>



211892  
**MINI BOL**  
MINI BOWL  
MINI BOL  
7,3 CM - 2 IN<sup>7/8</sup>  
7 CL - 2 OZ<sup>3/8</sup>



234208  
**MINI BOL**  
MINI BOWL  
MINI BOL  
7,3 CM - 2 IN<sup>7/8</sup>  
7 CL - 2 OZ<sup>3/8</sup>



230823  
**MINI BOL**  
MINI BOWL  
MINI BOL  
7,3 CM - 2 IN<sup>7/8</sup>  
7 CL - 2 OZ<sup>3/8</sup>

